


TORNADO



About Bearings



These are the three available styles of Tornado bearings

Figure 1 is a [1" snap-in bearing, part # 20515040](#). It is used on the Tornado Sport and Dynamo Blaster, and MAY fit older tables with a 1" sidewall that use a snap-in bearing.

Figure 2 is a [1 1/2" snap-in bearing, part # 20515992](#). It is used on the Tornado Classic and Dynamo Big D, and MAY fit older tables with a 1 1/2" sidewall that use a snap-in bearing.

Figure 3 is the [split bearing](#) and [bearing nut](#) combination used on Coin Foosball and T-3000 and similar split cabinet tables, and the Tornado Elite and Worthington. We have been asked if a table using press-in bearings can be modified to accept this bearing. **DON'T TRY IT**. The sidewall is usually the incorrect thickness, the holes are not large enough, and enlarging the holes while maintaining precise alignment will be EXTREMELY difficult. If done incorrectly, it will be impossible to repair your table.

Tornado makes no guarantees these bearings will fit a particular **old model of table. Or other manufacturer's tables**
Measure carefully before ordering.

