



**THE LEGS ARE SHIPPED WITH THE LEGS INSIDE THE TABLE
THE LEG BOLTS ARE NOW LOCATED ON THE INSIDE OF THE TRAP DOOR.
THE TRAP DOOR KEY IS SECURED TO THE OUTSIDE OF THE TRAP DOOR.**

1. Use your Service Door Key (# 54 Valley, # 106 Dynamo) to open the table's trap door.
2. Locate the bag of Leg bolts attached to the inside of the Trap Door and put them to the side.
3. Locate the 5/16" bolt used to hold the legs in place during shipment.
4. Using a 1/2" socket or wrench, remove the bolt and shipping block, freeing the legs.
5. Remove the legs one at a time through the Trap Door (more than one will not fit).
6. Replace the shipping block and bolt- you may need them to move the table at a later date.
7. Using a 1/2 socket, wrench, or large flat head screw driver, attach the legs to the table with the 5/16" - 18 bolts provided.
(It is best to attach the bottom legs first)
8. Once all legs have been attached, make sure all leg levelers are screwed in all the way. With two or more people, place the table onto the legs.
9. Follow the manual for further assembly instructions.