


OPEN THE CLEAN OUT DOOR ON THE CUE BALL RETURN END, AND CONNECT THE BATTERY
CHARGE FOR 6 HOURS, AND RECHARGE EVERY 2 WEEKS TO PREVENT BATTERY DAMAGE

In this template, the goal is to give you the basics of setting up your table.

Step 1 Open the **Bill Acceptor Coin Door**. Look on the **Left inner wall**, you will find our **logic board**.



Step 2 Locate the 3rd switch marked **SW2** on the **logic board**. **Press and hold the SW2** switch for **5 seconds** until the **display shows "Program Group / Time - Day"**.



NOTE: The rest of your programming will be done using your **3 buttons** mounted on the **coin door**.

Button functions:

Top (Start) Button

Use this button to **enter** a program group, make a **change forward** on an option, and to **execute** an option.

Middle (Select) Button

Use this button to go to the next option or program group

Bottom (Speed Pool) Button

Use this button to go **backwards** in an **option** or **program group**

Change the game Price. Factory setting Per Rack is \$2.00.

Time Play, bonus levels 2-3 and Happy Hours are set OFF.

Step 3 Press the **Middle (Select)** button 1 time and then the **Top (Start)** button to Enter **Game Options**.

Step 4 Press the **Middle (Select)** button 1 time and then either the **Top (Start)** or **Bottom (Speed Pool)** button to set the **price per game**.

If you are done with changes you can exit now or go to step 5 to change the total Bonus games issued for a \$5.

If done press the Middle (Select) button until you reach

"Program Group"
"Exit"

Press the Top (Start) to exit.

To Change the Bonus games given, go to Step 3. Factory setting is \$5.00 for 5 games.

Step 5 Press the **Middle (Select)** button 3 times, to reach the **L1 Bonus games issued**.

Step 6 Press either the **Top (Start)** or the **Bottom (Speed Pool)** buttons until you reach the **amount of games** you want to issue.

If you are done with changes, press the Middle (Select) button until you reach

"Program Group"
"Exit"

Press the Top (Start) to exit.

The chart on the back shows all options and ranges available. It can be used to program the week, or to adjust each day's settings, if desired.

Please see the back page for all available options per day, or refer to your owner's Manual for detailed instructions.

KEEPING YOUR BATTERY CHARGED WILL KEEP YOUR TABLE EARNING MONEY FOR YOU

OPEN THE CLEAN OUT DOOR ON THE CUE BALL RETURN END, AND CONNECT THE BATTERY
CHARGE FOR 6 HOURS, AND RECHARGE EVERY 2 WEEKS TO PREVENT BATTERY DAMAGE

Sub Groups	Min	Max	Default	New Setting
Sunday Rack Play	Off	On	On	
Sunday Rack Cost	0.25	\$20.00	\$2.00	
Sunday Group 1 Bonus Pricing	Off	On	On	
Sunday Group 1 Bonus Cost	\$1.00	\$20.00	\$5.00	
Sunday Group 1 Bonus Total Games Issued	2	40	5	
Sunday Group 2 Bonus Pricing	Off	On	Off	
Sunday Group 2 Bonus Cost	\$1.00	\$20.00		
Sunday Group 2 Bonus Total Games Issued	2	40		
Sunday Group 3 Bonus Pricing	Off	On	Off	
Sunday Group 3 Bonus Cost	\$1.00	\$20.00		
Sunday Group 3 Bonus Total Games Issued	2	40		
Sunday Time Play	Off	On	Off	
Sunday Time Cost	\$0.25	\$60.00		
Sunday Play Minutes	5	120		
Sunday Time Bonus	Off	On	Off	
Sunday Time Bonus Cost	\$0.25	\$60.00		
Sunday Time Bonus Total Minutes Issued	5	120		
Sunday Happy Hour 1	Off	On	Off	
Sunday Happy Hour Start Time	0:00	0:00		
Sunday Happy Hour 1 Duration	0:15	0:00		
Sunday Happy Hour 1 Rack	Off	On	Off	
Sunday Happy Hour 1 Rack Cost	\$1.00	\$20.00		
Sunday Happy Hour 1 Time	Off	On	Off	
Sunday Happy Hour 1 Time Cost	\$0.25	\$20.00		
Sunday Happy Hour 1 Time Minutes	5	120		
Sunday Happy Hour 2	Off	On	Off	
Sunday Happy Hour Start Time	0:00	23:45		
Sunday Happy Hour 2 Duration	0:15	24:00:00		
Sunday Happy Hour 2 Rack	Off	On	Off	
Sunday Happy Hour 2 Rack Cost	\$0.25	\$20.00		
Sunday Happy Hour 2 Time	Off	On	Off	
Sunday Happy Hour 2 Time Cost	\$0.25	\$20.00		
Sunday Happy Hour 2 Time Minutes	5	120		
Sunday Happy Hour 3	Off	On	Off	
Sunday Happy Hour Start Time	0:00	23:45		
Sunday Happy Hour 3 Duration	0:15	120		
Sunday Happy Hour 3 Rack	Off	On	Off	
Sunday Happy Hour 3 Rack Cost	\$0.25	\$20.00		
Sunday Happy Hour 3 Time	Off	On	Off	
Sunday Happy Hour 3 Time Cost	\$0.25	\$20.00		
Sunday Happy Hour 3 Time Minutes	5	120		
Copy Sunday for the Week	No	Yes	Yes	
Copy Sunday for the Weekend	No	Yes	No	
Do not Copy Sunday	No	Yes	No	

Please see the back page for all available options per day, or refer to your owner's Manual for detailed instructions.
 KEEPING YOUR BATTERY CHARGED WILL KEEP YOUR TABLE EARNING MONEY FOR YOU